


I-POWER AC to DC Transformer User Manual

- ① L-AC: AC Input terminal
Live line (fuse in line)
- ② N-AC: AC Input terminal
Neutral line
- ③ FG: Terminal FG
Safety earth (Frame Ground)
Connect to safety ground of apparatus
or equipment.
- ④ GND: -Output terminal
- ⑤ GND: -Output terminal
- ⑥ +12V: +Output terminal
- ⑦ +12V: +Output terminal



rcMart.com